



N1540 Process Indicator

UNIVERSAL INDICATOR – INSTRUCTIONS MANUAL – V2.0x

PRESENTATION

N1540 is a quite versatile process indicator. With a wide list of input types - thermocouples, thermo-resistance, voltage and current – the N1540 is capable of measuring the majority of the variables and sensors encountered in industrial processes.

It contains two alarms (six functions), sensor offset, configuration of parameters protected by password, serial communication, indication in degrees Celsius (°C) or Fahrenheit (°F), among others.

The configuration can be performed directly on the indicator or through the USB interface. The *NConfig* software (free) is the configuration management tool. Connected to the USB of a *Windows* computer, the indicator is recognized as a serial communications port (COM) running with a Modbus RTU protocol.

Through the USB interface, even if disconnected from the power supply, the configuration performed in a piece of equipment can be saved in a file and repeated in other pieces of equipment that require the same configuration.

FEATURES

SIGNAL INPUT (TYPE)

The input type to be used by the indicator is defined in the equipment configuration. **Table 01** presents the input options available for the user.

TYPE	CODE	RANGE OF MEASUREMENT
J	tc J	Range: -110 to 950 °C (-166 to 1742 °F)
K	tc K	Range: -150 to 1370 °C (-238 to 2498 °F)
T	tc t	Range: -160 to 400 °C (-256 to 752 °F)
N	tc n	Range: -270 to 1300 °C (-454 to 2372 °F)
R	tc r	Range: -50 to 1760 °C (-58 to 3200 °F)
S	tc S	Range: -50 to 1760 °C (-58 to 3200 °F)
B	tc b	Range: 400 to 1800 °C (752 to 3272 °F)
E	tc E	Range: -90 to 730 °C (-130 to 1346 °F)
Pt100	Pt	Range: -200 to 850 °C (-328 to 1562 °F)
0-20 mA	L0.20	Analog Linear Signal Indication programmable from -2000 to 30000.
4-20 mA	L4.20	
0-50 mV	L0.50	
0-5 V DC	L0.5	
0-10 V DC	L0.10	
4-20 mA NON LINEAR	Ln J	Non Linear Analog Signal Indication range according to the associated sensor.
	Ln K	
	Ln t	
	Ln n	
	Ln r	
	Ln S	
	Ln b	
	Ln E	
	LnPt	

Table 01 – Inputs Types

ALARMS

The instrument has **two** alarm outputs: Alarm-1 and Alarm-2.

The alarms can assume the functions described on **Table 02**.

oFF	Alarm off.	
Lo	Alarm of the Absolute Minimum Value. It triggers when the value of the PV is below the value defined by the alarm <i>Setpoint</i> (SPA1 or SPA2).	
Hi	Alarm of the Absolute Maximum Value. It triggers when the value of the PV is above the value defined by the alarm <i>Setpoint</i> .	
dIF	Alarm of the Differential Value. In this function the parameters SPA1 and SPA2 represent errors (difference) between the PV and one reference value ALrF .	
dIFL	Alarm of the Minimum Differential Value. It triggers when the value of the PV is below the point defined by: ALrF-SPA1 (using alarm 1 as an example).	
dIFH	Alarm of the Maximum Differential Value. It triggers when the value of the PV is above the point defined by: ALrF+SPA1 (using alarm 1 as an example).	
iErr	Alarms of the Sensor Break (Sensor <i>Break Alarm</i>). It is activated when the Input presents problems such as interrupted sensor, bad connection, etc.	

Table 02 – Alarm Functions

Note: The figures are also valid for Alarm 2 (SPA2).

BLOCKING INITIAL OF THE ALARM

The **initial blocking** option inhibits the alarm from being recognized if an alarm condition is present in the process when the indicator is first energized. The alarm will be enabled only after the occurrence of no alarm condition.

The initial blocking is useful, for example, when one of the alarms is set up as a minimum value alarm, which may cause the activation of the alarm soon upon the process start-up; an occurrence that may be undesirable in many cases.

The initial blocking is not valid for the function **iErr** (Sensor Break).

OFFSET

Allows fine adjustments to the PV indication, correcting measurement errors that appear, for example, after the replacement of the temperature sensor.

MAXIMUM AND MINIMUM

The indicator memorizes the measured maximum and minimum values (peak and valley). The operator can observe these extreme values at any time. These two values are shown when pressing the F1 (maximum) and F2 (minimum) keys. Pressing both keys simultaneously will clear the memory for a new peak and valley detection.

To clear the stored values and begin a new cycle of monitoring endpoints, just press the F1 and F2 keys **simultaneously**. When turn off the indicator this information is not saved.

CUSTOM LINEARIZATION

This feature allows accurate measurement of the input signals with nonlinear characteristics.

Linearization consists in dividing the calibration curve of the input signal into segments of variable gain. Each segment consists of a start and an end. For each input value (*inP.xx*) a respective output indication (*ouP.xx*) is defined.

The input signal must present an always-crescent.


Applied to input types 0-20 mA, 4-20 mA, 0-50 mV, 0-5 V and 0-10 V.

24 VDC AUXILIARY VOLTAGE SOURCE

The standard version of the N1540 provides an auxiliary power supply for exciting field transmitters (terminals 11 and 13 on the rear panel).

SERIAL COMMUNICATION

Follows a description of the usual communication registers. For full documentation download the **Registers Table N1540 for Serial Communication** on our web site – www.novusautomation.com.



USB INTERFACE

The USB interface is used for CONFIGURING or MONITORING the indicator. The *NConfig* software must be used for the configuration. It makes it possible to create, view, save and open configurations from the equipment or files in your computer. The tool for saving and opening configurations in files makes it possible to transfer configurations between pieces of equipment and to make backup copies. For specific models, the *NConfig* software also makes it possible to update the firmware (internal software) of the indicator through the USB.

For MONITORING purposes you can use any supervisory software (SCADA) or laboratory software that supports the MODBUS RTU communication on a serial communications port. When connected to the USB of a computer, the indicator is recognized as a conventional serial port (COM x). Use the *NConfig* software or consult the DEVICE MANAGER in the Windows CONTROL PANEL to identify the COM port that was assigned to the indicator. Consult the mapping of the MODBUS memory in the indicator's communications manual and the documentation of your supervisory software to conduct the MONITORING process.

Follow the procedure below to use the USB communication of the equipment:

1. Download the *NConfig* software from our website and install it on your computer. The USB drivers necessary for operating the communication will be installed together with the software.
2. Connect the USB cable between the equipment and the computer. The indicator does not have to be connected to a power supply. The USB will provide enough power to operate the communication (other equipment functions cannot operate).
3. Open the *NConfig* software, configure the communication and start recognition of the device.
4. Consult the *NConfig* help desk for detailed instructions about how to use it and solve problems.

	<p>The USB interface IS NOT SEPARATE from the signal input (PV) or the indicator's digital inputs and outputs. It is intended for temporary use during CONFIGURATION and MONITORING periods. For the safety of people and equipment, it must only be used when the piece of equipment is completely disconnected from the input/output signals. Using the USB in any other type of connection is possible but requires a careful analysis by the person responsible for installing it. When MONITORING for long periods of time and with connected inputs and outputs, we recommend using the RS485 interface, which is available or optional in most of our products.</p>
--	--

INSTALLATION / CONNECTIONS

The indicator is meant for panel mounting. The sequence of steps is:

- Prepare a cut-out of 93.0 by 45.5 mm on the panel;
- Remove the mounting clamp from the indicator;
- Insert the indicator into the cut-out from the front side of the panel;
- Place the clamp on the indicator again, pressing until firm grip to the panel.

SAFETY ALERTS

The symbols below are used on the equipment and throughout this manual in order to draw the user's attention to important information related to the equipment safety and operation.

<p>CAUTION: Read the manual thoroughly before installing and operating the instrument</p>	<p>CAUTION OR DANGER: Electrical shock hazard</p>

All safety related instructions that appear in the manual must be observed to ensure personal safety and to prevent damage to either the instrument or the system. If the instrument is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

ELECTRICAL CONNECTIONS

The terminals configurations are shown in **Figure 01**.




Figure 01 – Inputs connections and power supply




Figure 02 – Thermocouple, Pt100 and 50 mV signal connection




Figure 03 – Current (mA) and Voltage (V) signal connection

This indicator offers an auxiliary 24 Vdc power supply which is typically applied to power up two wire 4-20 mA field transmitters. The **Figure 04** presents the wiring for this application.




Figure 04 – Auxiliary 24 Vdc usage example

RECOMMENDATIONS FOR THE INSTALLATION

- To minimize the pick-up of electrical noise, the low voltage DC connections and the sensor input wiring should be routed away from high-current power conductors. If this is impractical, use shielded cables. In general, keep cable lengths to a minimum.
- The input signals conductors shall be positioned throughout the factory separate from the output and the power supply conductors, in grounded conduits if possible.
- The power supply of the electronic instruments shall come from a proper source for the instrumentation network.
- It is recommended to use RC FILTERS (0,1 uF in series with 100 ohms) to suppress the noise generated by contactors coils, solenoids, etc.

OVER-TEMPERATURE PROTECTION

When designing any control system it is essential to consider what will happen if any part of the system should fail. In temperature control applications the primary danger is one in which the heating remains constantly on. In any application where physical injury or destruction of equipment might occur, it is recommend to install an independent protection equipment, with a separate temperature sensor, to disable the heating circuit in case of overheating. Please note that the alarm relays within the indicator will not give protection under all failure conditions.

OPERATION

The indicator front panel, together with its elements, can be seen on **Figure 02**:



Figure 02 - Identification of the front panel parts

Display: Shows the process variable **PV**, the configuration parameters prompts and their respective values/conditions.

Indicators A1 and A2: signalize the occurrence of an alarm condition.

Key P: used to walk through the parameters in the menu cycles.

F1 / ▲ key and F2 / ▼ key: Used to change parameter values.

Key ◀: go back to the previous displayed parameter.

START UP

When the indicator is powered up, its firmware version is displayed for 3 seconds, after which the **N1540** starts normal operation, when the value of **PV** is displayed and the outputs are enabled.

Before the indicator is ready to be used in a given process, it requires some basic configuration, consisting of assigning values to the parameters according to the desired behavior. The user shall understand the importance of each parameter and determine a valid condition or a valid value for each one of them.

The configuration parameters are grouped in levels according to their affinity. The 4 parameters levels are:

- 1 – Operation
- 2 – Alarms
- 3 – Input
- 4 – Calibration

The **“P”** key provides the access to the levels and to the parameters of these levels.

Keeping the **P** key pressed, at every 2 seconds, the indicator jumps from one level to another, presenting the first parameter of each level:

PV >> FUR I >> TYPE >> PASS >> PV ...

To enter into a particular level, simply release the **P** key when the first parameter in that level is displayed.

To walk through the parameters in a level, press the **P** key with short strokes. To go back to the previous parameters, use the **◀** Key.

The display alternates the presentation of the parameter prompt and its value. The parameter value is displayed with a light blinking to differentiate it from the parameter prompt.

Depending on the level of parameter protection adopted, the parameter **PASS** precedes the first parameter in the level where the protection is active. See section **PROTECTION CONFIGURATION**.

DESCRIPTION OF THE PARAMETERS

OPERATION CYCLE

PV	Indication Display of PV. The value of the measured variable (PV) is shown on the upper display (red).
SPA1 SPA2	Alarm SP: Value that defines the alarm activation point. For the alarms set up with the functions of the type Differential , these parameters define the maximum differences accepted between PV and a reference value defined in the parameter ALrF . For the alarm function IErr , this parameter is not used. Parameters shown in this level only when enabled in the parameters SP1E and SP2E .

ALARMS CYCLE

FuA1 FuA2	Alarm Functions. It defines the functions of the alarms among the options in Table 02.
ALrF	Reference value used by the alarms with differential function, minimum differential or maximum differential.
SPA1 SPA2	Alarm SP: Value that defines the point of activation of the alarm outputs. For the alarms programmed with the functions of the type Differential , these parameters represent the deviations. For the IErr alarm function, this parameter has no meaning.
SP1E SP2E <i>SP Enable</i>	It allows the parameters SPA1 and SPA2 to be displays also in the indicator operation cycle. YES shows the parameters SPA1/SPA2 in the operation cycle no Does not show the parameters SPA1/SPA2 in the operation cycle
bLA1 bLA2 <i>Blocking Alarm</i>	Alarms Initial Blocking. YES enables the initial blocking no inhibits the initial blocking
HYA1 HYA2 <i>Hysteresis of Alarm</i>	Alarm Hysteresis. It defines the difference between the value of PV at which the alarm is triggered and the value at which it is turned off.
FLSh Flash	It allows signalization of an alarm conditions occurrence by flashing the indication of PV on the indication display. YES Enables alarm signalization by flashing PV. no Disables the flashing PV.

INPUT CYCLE

tYPE <i>Type</i>	Input Type. Selection of the input type, used by the indicator. Refer to Table 01.
FLtr <i>Filter</i>	Digital Input Filter – Used to improve the stability of the measured signal (PV). Adjustable between 0 and 20. At 0 (zero) it means filter turned off and 20 means maximum filter. The higher the filter value, the slower is the response of the measured value.
dPPo <i>Decimal Point</i>	It determines the position of the decimal point on the display.
un: t <i>Unit</i>	It defines the temperature unit to be used: C Indication in Celsius. F Indication in Fahrenheit.
OFFS <i>Offset</i>	Parameter that allows the user to make fine adjustments to the indicated PV value.

mLL <i>Input Low Limit</i>	It defines the <u>lower</u> value of the indication range when the input types of 0-20 mA, 4-20 mA, 0-50 mV, 0-5 V and 0-10 V are used.
mHL <i>input High Limit</i>	It defines the <u>upper</u> value of the indication range when the input types of 0-20 mA, 4-20 mA, 0-50 mV, 0-5 V and 0-10 V are used.
bAud <i>Baud Rate</i>	Baud Rate of the serial communication. In kbps. 1.2, 2.4, 4.8, 9.6, 19.2, 38.4, 57.6 and 115.2
PrEtY <i>Parity</i>	Parity of the serial communication. nonE Without parity EuEn Even parity Odd Odd parity
Addr <i>Address</i>	Communication Address. A number that identifies the indicator in the serial communication network, between 1 and 247.

CUSTOM LINEARIZATION CYCLE

LEnbl	Enables custom linearization. When you enable this parameter, the display shall meet the requirements set points defined in the parameters below.
inP.DD inP. ID	Defines the extreme points of each segment of the customized linearization. Values must be in the same unit as the input signal.
out.DD out. ID	Sets the values corresponding to the respective segment of the customized linearization. Values must be in the same unit as the measured quantity (within the Upper and Lower Indication Limits).

CALIBRATION CYCLE

All types of input are calibrated in the factory. In case a recalibration is required; it shall be carried out by a specialized professional. In case this cycle is accidentally accessed, do not perform alteration in its parameters. The factory calibration can be restored in the parameter **rStE**.

PASS	<u>Password</u> . Entering the Access password. This parameter is presented before the protected cycles. See item Protection of Configuration.
CAL Ib	<u>Calibration</u> . Enables the possibility for calibration of the indicator. When the calibration is not enabled, the related parameters are hidden.
inLC	<u>Input Low Calibration</u> . Indication of the low scale calibration signal applied to the input.
inHC	<u>Input High Calibration</u> . Indication of the full scale calibration signal applied to the input.
rStE	<u>Restore</u> . It restores the factory calibrations of the input, disregarding any modifications carried out by the user.
CJ	<u>Cold Junction</u> . Temperature of the indicator cold junction.
PASC	<u>Password Change</u> . It allows the definition of a new access password, always different from zero.
Prot	<u>Protection</u> . Sets up the Level of Protection. See Table 03.
FrEQ	<u>Frequency</u> . Frequency of the local electrical network.
Sn H	First part of the indicator serial number.
Sn L	Second part of the indicator serial number.

PROTECTION CONFIGURATION

The indicator provides means for protecting the parameters configurations, not allowing modifications to the parameters values, avoiding tampering or improper manipulation. The parameter **Protection (Prot)** in the Calibration level determines the protection strategy, limiting the access to particular levels, as shown in the table below.

Protection Level	Protected Levels
1	Only the Calibration level is protected.
2	Custom Linearization and Calibration levels are protected.
3	Input, Custom Linearization and Calibration levels are protected.
4	Alarms, Input, Custom Linearization and Calibration levels are protected.

Table 03 – Levels of Protection of the Configuration

ACCESS PASSWORD

The protected levels, when accessed, request the user to provide the **Access Password** for granting permission to change the configuration of the parameters on these levels.

The prompt **PR55** precedes the parameters on the protected levels. If no password is entered, the parameters of the protected levels can only be visualized.

The Access Password is defined by the user in the parameter **Password Change (PR5C)**, present in the Calibration Level. The factory default for the password code is 1111.

PROTECTION OF THE ACCESS PASSWORD


The protection system built into the indicator blocks for 10 minutes the access to protected parameters after 5 consecutive frustrated attempts of guessing the correct password.

MASTER PASSWORD

The Master Password is intended for allowing the user to define a new password in the event of it being forgotten. The Master Password doesn't grant access to all parameters, only to the **Password Change** parameter (**PR5C**). After defining the new password, the protected parameters may be accessed (and modified) using this new password.

The master password is made up by the last three digits of the serial number of the indicator **added** to the number 9000.

As an example, for the equipment with serial number 07154321, the master password is 9 3 2 1.

The indicator serial number can be obtained by pressing  for 5 seconds.

SPECIFICATIONS

DIMENSIONS:..... 96 x 48 x 35 mm (1/16 DIN)

Panel Cut-out.....93.0 x 45.5 mm

Approximate Weight: 110 g

POWER SUPPLY:.....100 to 240 Vac/dc (±10 %), 50/60 Hz

Optional 24 V:12 to 24 Vdc / 24 Vac (-10 % / +20 %)

Maximum consumption:..... 6 VA

ENVIRONMENTAL CONDITIONS:

Operation Temperature: 0 to 50 °C

Relative Humidity:.....80 % @ 30 °C

For temperatures above 30 °C, reduce 3 % per °C. Indoor use; Installation Category II, Pollution Degree 2; altitude < 2000 m.

INPUTAccording to **Table 01**

Internal Resolution:.....32767 levels (15 bits)

Display Resolution:..... 32000 levels (from -2000 to 30000)

Temperature Resolution:..... 0.1 / 1 °F / °C

Input reading rate:up to 55 per second

Precision: ... Thermocouples J, K, T, E: 0.25 % of the span ±1 °C

..... Thermocouples N, R, S, B: 0.25 % of the span ±3 °C

..... Pt100: 0.2 % of the span

..... 4-20 mA, 0-50 mV, 0-5 V, 0-10 V: 0.2 % of the span

Input impedance: Pt100, thermocouples, 0-50 mV: > 10 MΩ

..... 0-5 V, 0-10 V: > 500 kΩ

..... 4-20 mA: 100 Ω

Measuring of the Pt100:3 wire type, (α=0.00385)

With compensation of the cable length, max 50 meters, excitation current of 0.170 mA.

OUTPUT ALARM1:.....Relay SPST; 240 Vac / 30 Vdc / 1.5 A

OUTPUT ALARM2:.....Relay SPST; 240 Vac / 30 Vdc / 1.5 A

24 VDC SOURCE: 24 Vdc (±10 %) / 20 mA max.



CASE: Polycarbonate (PC) UL94 V-2

BACK PANEL:..... ABS+PC UL94 V-0

CONNECTIONS (WIRING): Plug-in block terminals, 5 mm pitch

USB INTERFACE: 2.0, CDC class (virtual communications port), MODBUS RTU protocol.

STARTS OPERATION: after 3 seconds connected to the power supply.

CERTIFICATIONS:  

IDENTIFICATION

N1540	Basic version.
N1540-24	Basic version with power supply 24 V
N1540-485	With serial communication RS485.
N1540-485-24	Version with RS485 and power 24 V

MAINTENANCE

PROBLEMS WITH THE INDICATOR

Connection errors and inadequate programming are the most common problems encountered during the indicator operation. A final revision can avoid loss of time and damages.

The indicator displays some messages to help the user identify the problems.




MESSAGE	DESCRIPTION OF THE PROBLEM
----	Open input. Without sensor or signal.
Err 1 Err 6	Connection and/ or configuration problems. Check the wiring and the configuration.




Other error messages may indicate hardware problems requiring maintenance service.

CALIBRATION OF THE INPUT

All inputs are factory calibrated and recalibration should only be done by qualified personnel. If you are not familiar with these procedures do not attempt to calibrate this instrument.

The calibration steps are:

- Configure the input type to be calibrated.
- Configure the lower and upper indication limits for the maximum span of the selected input type.
- Connect to the input terminals a signal corresponding to a known indication value a little above the lower display limit.
- Access the parameter **InLc**. With the keys  and  adjust the display reading to match the applied signal. Then press the  key to store.

- e) Inject a signal that corresponds to a value a little lower than the upper limit of indication.
- f) Access the parameter **lnhc**. With the keys  and  adjust the display reading to match the applied signal. Then press the  key to store.

Note: When checking the indicator calibration with a Pt100 simulator, pay attention to the simulator minimum excitation current requirement, which may not be compatible with the 0.170 mA excitation current provided by the indicator.

SUPPORT AND MAINTENANCE

This product contains no serviceable parts inside. Contact our local distributor in case you need authorized service. For troubleshooting, visit our FAQ at www.novusautomation.com.

SAFETY INFORMATION

Any control system design should take into account that any part of the system has the potential to fail. This product is not a protection or safety device and its alarms are not intended to protect against product failures. Independent safety devices should be always provided if personnel or property are at risk.

Product performance and specifications may be affected by its environment and installation. It's user's responsibility to assure proper grounding, shielding, cable routing and electrical noise filtering, in accordance with local regulations, EMC standards and good installation practices.

LIMITED WARRANTY AND LIMITATION OF LIABILITY

NOVUS warrants to the original purchaser that this product is free from defects in material and workmanship under normal use and service within one (1) year from the date of shipment from factory or from its official sales channel to the original purchaser.



1295 Morningside Ave., Unit 16-18
 Scarborough, ON M1B 4Z4 Canada
 Phone: 416-261-4865 Fax: 416-261-7879
www.scigiene.com