

MARATHON C\TEMP DATALOGGER INSTRUCTIONS

The operation of the [c\temps](#) is fairly easy as they come preprogrammed with run times, and alarms set as per customer requirements (if you need help here please let us know and we will be happy to help)

Basic operation:

- 1) When ready to place the datalogger in a shipment (record serial number and write anything required on the datalogger first) and press the black start button. Ensure the datalogger is working. Does the GREEN LED flash 3 times slowly when the button is pushed? If not, try again and if this fails it could mean the unit was previously started (though this is usually indicated by periodic green or red LED flashes*) or the unit is damaged or that the battery is possibly dead. In any event if the lights do not flash DO NOT use, and replace the suspect unit with another functional unit. Call us in regards to failed unit for instructions later.
- 2) Upon receipt of the unit if the GREEN LED flashes intermittently, then all is good provided the alarm points were set correctly.
- 3) If the RED LED flashes periodically then alarm settings have been exceeded. The shipment should be quarantined and the datalogger downloaded by Authorized persons for review to decide if the product can be released or whether further testing needs to be done.



*If the LED's flash periodically it means the unit has already been started so unless you know absolutely when the unit was started it should be placed aside and another used. We occasionally get calls wondering where the trip data went and when we check the units we discover it was started a week ago and recorded the office temperature for a week before shipping.



1295 Morningside Ave Units 16, 17, & 18
Toronto ON M1B 4Z4 Canada
Telephone: 416-261-4865 Fax: 416-261-7879
www.scigiene.com